


ST290 Graphic Display - quick reference guide

ST290 Graphic Display FAVORITE pages


The **FAVORITE** chapter gives **quick, easy access** to data you use most often


- You can set any number of FAVORITE pages from 1 to 5.
- You can allocate any available data to a FAVORITE page. For example:
 - Alphanumeric data (e.g. speed, depth etc).
 - Animated graphics (e.g.rolling road, docking etc).
 - RayTech channels. These provide data calculated by RayTech Sail Racer.
- You can set up a FAVORITE page in any format:
 - Single data - one data box is displayed.
 - Dual data - two data boxes are displayed.
 - Quad data - four data boxes are displayed.

To see your FAVORITE pages



FAVORITE chapter

If the FAVORITE pages do not roll around automatically, one after the other, use  to manually select pages.




D6259-1

ST290 Graphic Display FAVORITE pages


How to set up what you see on the FAVORITE pages


1.

Select the FAVORITE page you want to set up (see page 1 of this guide).





2.


Hold down  for 2 s to enter setup mode.




3.

Use  or  to select either single, dual or quad element page format, at the setup menu.


The page format changes to match the selected format.




4.

Use  to cycle through the available data, until the information you want is displayed in the highlighted area.

5.


Use  to select the next editable page area, and repeat step 4




6.

Repeat steps 1 to 5 for each FAVORITE page you want to set up.

7.

When you have finished setting up the FAVORITE pages, hold down  for 2 s, to return to Normal operation and save your new settings.




ST290 Graphic Display FAVORITE pages


How to set the number of FAVORITE pages

You can set up your FAVORITE chapter to show any number of pages, from 1 to 5.

Enter User Setup




User setup





ST290 Graphic Display FAVORITE pages


How to set the method of selecting FAVORITE pages

You can set the method of selecting FAVORITE pages. This is:


- **Either** so you manually select pages, using 



- **Or** so the FAVORITE pages roll around automatically.




Enter User Setup



User setup


FAVORITES setup



Use  or  to set method of FAVORITE page selection:

- If you want to select FAVORITE pages manually, set to OFF.
- If you want FAVORITE pages to roll around automatically, set the time you want each page to be displayed (from 0.5 s to 20 s).

Leave User Setup



2 s

Normal operation

D6285-1